

## Programming Remote for your TV

Contact us at 888-508-2946 or visit [www.westianet.com](http://www.westianet.com) for more information.



**While the TV is powered on, perform the following instructions to program your remote to control your TV:**

1. Press “TV” (TV button should flash once).
2. Hold “Setup” until TV button flashes twice.
3. Press “991”
4. Press the channel up (+) button until your TV turns off. (Some TV’s may take a couple of minutes with multiple channel up (+) clicks before the code is found.)
5. When your TV powers off, press “Power” to turn your TV back on. If your TV powers on, follow step 6. If your TV does NOT power on, skip to step 7.
6. If your TV is powered back on press the setup button until the TV button flashes twice.
7. Press channel down (-) until your TV turns on. Once your TV has powered back on, press the “setup” button until the TV button flashes twice.